

Folding Guide

Many of the more common folds are shown in the following diagrams. Certain folds require "short panels" to allow the finished piece to remain flat. The short panels are identified on the pictures below. The amount of trim for the short panels will depend upon the weight and type of stock used in your project, but a safe measurement is 1/16th of an inch. Use the supplied panel dimensions and dimension calculators to help make sure your project folds correctly. For specific information about your project, contact your Sales or Customer Service Representative.

Single, Accordion & French Fold



Single Fold
(four panels)



Accordion (or "Z") Fold
(usually six or eight panels)




French Fold
(eight panels)

Letter Fold




Letter Fold
(six panels)


11 x 17 (tabloid size)



8 1/2 x 11 (letter size)



8 1/2 x 14 (legal size)



When doing a trifold, divide your paper width by 3 (ie, on an 8 1/2 x 11 sheet, divide 11 by 3 to get 3.6667). Round that number up to nearest 32nd of an inch (ie, 3.6875). This number will be the size of your two wide panels. To get the third (short) panel, subtract a 16th, or .0625 from the wide panel size (ie, 3.625). The form below will do the work for you, but, since trifolds work with thirds (uneven numbers), the measurements are not always exact (ie, if you add the three numbers together, the sum does not exactly equal the original size). The results are extremely close and are usable.

